


I N S T E O N[®]



INSTEON Hub
Quick Start Guide

INSTEON Hub

Status LED



Idle



Linking



Unlinking



Factory Reset



Ethernet Port

Power




Ethernet
Cable



Power
Cable


Installation

Connect your Hub to the internet and a power outlet using the cables provided. Avoid switched outlets or power strips.



Download the App


From your mobile device, download and install **INSTEON for Hub** from your device's app store.



Don't feel like searching? Scan the QR Code and tap your store.

Create an Account


Launch the App and follow the on-screen instructions to create an account and setup the INSTEON Hub.



You're done setting up your INSTEON Hub; now start adding devices.


Adding Devices

You can add devices by tapping Add a Device found in the drawer. Follow the on-screen instructions to add light switches, sensors, cameras and more.



Create a Scene

Control a single light or a group of devices simultaneously. Visit Scenes and then tap Add.



Trigger a Scene


Sensors can activate scenes. To setup a trigger, simply add a sensor to a scene.



INSTEON Motion, Open/Close, Door and Leak Sensors sold separately.

Create a Schedule

Assign a schedule to individual devices or scenes. Go to the device or scene properties and tap Schedule.



Configure Alerts

Receive an email alert when a sensor or device is activated. Enable alerts by visiting the device properties and tapping Alerts.



Remote Access

Hub 2 automatically configures itself for remote access so you can control and monitor your home from anywhere in the world.



Learn More

For the complete Owner's Manual, video tutorials, product support and more, visit:
insteon.com/support

